

FENDER "TWIN-AMP" LAYOUT

MODEL 5C8

NOTICE ALL VOLTAGES
READ TO GROUND WITH ELECTRONIC
VOLTMETER. VALUES SHOWN $\pm 20\%$

